



# **Opal Pro MS6 SERIES**

## **AB Ethernet IP Interface Users Manual**

*Revision 1.00*



## **FOR YOUR SAFETY**

Only qualified personnel should install this equipment, after first reading and understanding all the information in this manual. All instructions should be strictly adhered to. The user should consult Brock Solutions or a SAF OPAL Starters supplier for clarification of the contents of this manual should any doubt or questions arise.

The installation of this equipment must be conducted in accordance with all national, regional and local electrical codes.

All drawings and technical representations included in this manual are for typical installations and should not in any way be considered for specific applications or modifications. Consult SAF OPAL Starters for supplemental instructions.

Brock Solutions Inc. accepts no liability for any consequences resulting from inappropriate, negligent or incorrect installation, application or adjustment of this equipment.

The contents of this manual are believed to be correct at the time of printing. In following with our commitment to the ongoing development and improvement of our products SAF OPAL Starters reserves the right to change the specification of this product and/or the content of this instruction manual without notice.



## Table of Contents

INTRODUCTION .....	6
HARDWARE .....	6
JUMPER SETTINGS.....	6
LED INDICATORS .....	7
OPAL PRO PARAMETER SETTINGS .....	8
I/O CONFIGURATION.....	10

# Opal Pro to Mod TCP

## Introduction

The Opal Pro can be monitored and controlled over an Ethernet communication network using the AB Ethernet IP protocol. The Opal Pro connects to the Ethernet network through an optional Ethernet card that is mounted on the main Opal Pro control card (CA530). Access is gained to the Ethernet card via the communication opening on the right side of the Opal Pro. The Opal Pro is an AB Ethernet IP slave and is mapped as I/O through an Ethernet bridge

## Hardware

Connection is made via a 10Mbaud Ethernet port which utilizes a RJ45 connector. Connection should be made using CAT 5 cable.

## Jumper Settings

Jumper	Setting	Description
J3	Not installed	Boot Block write enable
J4	Installed on pins 1 and 2	Disable test mode

## LED Indicators

Two bi-colour (red/green) LED indicators are mounted beside the network connector. The upper LED indicates the Ethernet interface card status.

LED State	Ethernet Interface Card Status
OFF	No power
Flashing Red	Recoverable configuration fault (card is not configured, contact Brock Solutions for support)
Solid Red	Hardware Error (contact Brock Solutions for support)
Flashing Green	No errors client interface is not open ( check software firmware version of Opal Pro)
Solid Green	No errors (normal operation)
Amber (Red/Green)	Configuration Mode (card is not configured, contact Brock Solutions for support)

The lower LED indicator indicates the Ethernet Network status.

LED State	Ethernet Network Status
OFF	Network interface offline, No network power
Flashing Red	I/O connection in timed-out state or other Recoverable fault
Flashing Green	Device in online but has no connections
Solid Red	Unrecoverable fault
Solid Green	Online with established connections
Amber (Red/Green)	Device is in Communication Faulted state and responding to an Identify Communication Faulted Request

## Opal Pro Parameter Settings

The parameters in the Opal Pro used to configure the Ethernet interface card (group 14) are only accessible if a Ethernet interface card is installed. The parameter settings are as follows:

<b>Opal Pro Parameter</b>	<b>Setting</b>	<b>Description</b>
2.02 Comm Module	Ethernet	Type of interface card installed (read only)
10.01 Start/Stop	Comm Module	This allows the Opal Pro to be started and stopped over the communication link
10.04 Iref Source	Comm Module	If this is set to Comm Module the Opal pro will follow the Current reference from the communication link. If there is no reference being sent on the communication link this should be set to "Internal"
10.05 Phase Angle Source	Comm Module	If this is set to Comm Module the Opal pro will follow the Phase Angle reference from the communication link. If there is no reference being sent on the communication link this should be set to "Internal"
14.07 Node	1 – 254	This is the Node # of the slave Opal Pro
14.08 IP Addr 1	0-255	First number in the IP address of the Opal Pro
14.09 IP Addr 2	0-255	Second number in the IP address of the Opal Pro
14.10 IP Addr 3	0-255	Third number in the IP address of the Opal Pro
14.11 IP Addr 4	0-255	Fourth number in the IP address of the Opal Pro. (the node number as set in 14.07 is added on to this number to get the final IP address)
14.12 SubNet 1	0-255	First number in the SubNet Mask
14.13 SubNet 2	0-255	Second number in the SubNet Mask
14.14 SubNet 3	0-255	Third number in the SubNet Mask
14.15 SubNet 4	0-255	Fourth number in the SubNet Mask



15.04 Comm Fault	Enable Disable	Enable – Opal Pro trips out on a communication fault Disable – Nothing happens on a communication fault
15.05 Comm Fault Time	0.1 to 5.0 secs	This is the time setting that the Opal Pro uses to detect a communication fault. Bit 15 of the command word must change state twice with in the time set in this parameter.

If parameters in group 14 are modified the changes do not take effect until the control power for the Opal Pro is turned off and then back on again.

## I/O Configuration

The Opal Pro supports 4 input words and 51 output words. Their description is as follows:

<b>Input Words (Polled)</b>	<b>AB Ethernet IP</b>	<b>Name</b>	<b>Description</b>
Word 1	Output Word 0	Command	Bit 0 – Run Command
			Bit 1 – Jog Command
			Bit 2 – Reverse Command
			Bit 3 – Reset Command
			Bit 4 – DCI/Soft Stop Enable
			Bit 5 – Reserved
			Bit 6 – Reserved
			Bit 7 – Reserved
			Bit 8 – Reserved
			Bit 9 – Reserved
			Bit 10 – Reserved
			Bit 11 – Reserved
			Bit 12 – Reserved
			Bit 13 – Reserved
			Bit 14 – Reserved
Bit 15 – Watch Dog bit (this bit must change at least twice in the time set by parameter 15.05)			
Word 2	Output Word 1	Current Reference	0 –1000, 833 = 500% of Motor Current set in parameter 13.01
Word 3	Output Word 2	Phase Angle Reference	0 – (0.5 * Line Freq Cycle time in usec) ie: 60 Hz 0 – 8333
Word 4	Output Word 3	Reserved	

<b>Output Words (Polled)</b>	<b>AB Ethernet IP</b>	<b>Name</b>	<b>Description</b>
Word 1	Input Word 0	Status	Bit 0 – Ready to Run (drive is enable and has 3 phase power)
			Bit 1 –Running (start is regulating)
			Bit 2 – Full On (starter is phased fully on)
			Bit 3 – Up to Speed (started is phased fully on and the current is below 105% of nameplate current as set in 13.01)
			Bit 4 – Reverse
			Bit 5 – Jogging
			Bit 6 – DC Injecting
			Bit 7 – Faulted
			Bit 8 – IOC Fault
			Bit 9 – MOL Fault
			Bit 10 – Phase Loss Fault
			Bit 11 – Shear Pin Fault
			Bit 12 – Shorted SCR Fault
			Bit 13 – Heat Sink OT Fault
			Bit 14 – Reserved
Bit 15 – Watch Dog Bit			
Word 2	Input Word 1	Current Feedback	833 = 500% of motor name plate current as set in 13.01
Word 3	Input Word 2	Phase Angle Actual	Amount of time phased on in microseconds
<b>Parameter</b>	<b>AB Ethernet IP</b>	<b>Name</b>	<b>Description</b>
1.01	Input Word 3	Current	Current feedback in Amps
1.02	Input Word 4	L1 to L2 Voltage	Line 1 to Line 2 Voltage in Volts
1.03	Input Word 5	L1 to L3 Voltage	Line 1 to Line 3 Voltage in Volts
1.04	Input Word 6	L2 to L3 Voltage	Line 2 to Line 3 Voltage in Volts
1.05	Input Word 7	DI Status	Digital input status
			Bit 0 – Start
			Bit 1 – Stop
			Bit 2 – Jog
			Bit 3 – Reverse
1.06	Input Word 8	Analog Input	Analog input value in Volts X 100

1.07	Input Word 9	Relay Status	Status of the Relay Outputs
			Bit 0 – Running
			Bit 1 – By-Pass
			Bit 2 – Shorted SCR
			Bit 3 – Reverse
			Bit 4 – Faulted
1.08	Input Word 10	Analog Output	Analog Output value in Volts X 100
2.01	Input Word 11	Stack Size	Opal Pro Stack Size in Amps
2.02	Input Word 12	Comm Module Type	0 – None 2 – Ethernet
2.03	Input Word 13	Firmware Version	Opal Pro Firmware Version x 100
10.01	Input Word 14	Start/Stop Control	4 = 2 Wire 5 = 3 Wire 6 = Comm Module
10.02	Input Word 15	Ramp Time	Time is seconds
10.03	Input Word 16	Step Current	In % of nameplate current
10.04	Input Word 17	Current Reference	7 = Internal 8 = Analog Input 9 = Comm Module
10.05	Input Word 18	Phase Angle	10 = Internal 11 = Analog Input 12 = Comm Module
10.06	Input Word 19	Jog Accel Current Limit	In % of nameplate current
10.07	Input Word 20	Jog Current Limit	In % of nameplate current
10.08	Input Word 21	Jog Ramp	Time is seconds x 10
11.01	Input Word 22	Stop Mode	13 = Coast 14 = Soft Stop 15 = DC Injection
11.02	Input Word 23	Soft Stop Step	In % of incoming line voltage
11.03	Input Word 24	Soft Stop Ramp	Time in seconds
11.04	Input Word 25	DCI Current	In % of nameplate current
11.05	Input Word 26	DCI Time	Time in seconds

12.01	Input Word 27	Analog Output	16 = Current Reference 17 = Current Feedback 18 = Overload level 19 = Phase Angle
13.01	Input Word 28	Motor Amps	Motor nameplate current in Amps
13.02	Input Word 29	Motor Volts	Motor nameplate volts in Volts
13.03	Input Word 30	Service Factor	Motor nameplate service factor x 100
14.01-14.06	Input Word 31- Input Word 36	Reserved	
14.07	Input Word 37	Node Number	1 – 254
14.08	Input Word 38	IP Address 1	0 – 255
14.09	Input Word 39	IP Address 2	0 – 255
14.10	Input Word 40	IP Address 3	0 – 255
14.11	Input Word 41	IP Address 4	0 – 255
14.12	Input Word 42	SubNet 1	0 – 255
14.13	Input Word 43	SubNet 2	0 – 255
14.14	Input Word 44	SubNet 3	0 – 255
14.15	Input Word 45	SubNet 4	0 – 255
15.01	Input Word 46	Shear Pin Flt	34 = Enabled 35 = Disabled
15.02	Input Word 47	MOL Fault	36 = Disabled 37 = Class 10 37 = Class 15 37 = Class 20 37 = Class 30
15.03	Input Word 48	Overload Level	In % Drive trips at 100%
15.04	Input Word 49	Comm Fault	41 = Enabled 42 = Disabled
15.05	Input Word 50	Comm Flt Time	Time in seconds x 10

**NOTE: The Opal Pro must have firmware version 1.70 or higher.**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>