Bluetooth Hot Sync Operation for Sony Clie and PALM TungstenT
Quick Setup Guide

For Sony Clie Models: NZ90, Peg-TG50, T665c- using Palm OS

<u>Use with Belkin Bluetooth Adapters: F8T001, F8T002, F8T003</u>

How to perform a Hotsync Operation with a Sony Clie

Section 1: <u>Enabling the Bluetooth on the Sony Clie.</u>

1. Tap on **Preferences,** on the upper right side corner tap on the pull down error and select Bluetooth.
2. Make sure that **Bluetooth:** is turned on
3. **Device name:** anything you want to name you're Clie
4. Allow Device To be Discovered : **Yes**
5. Allow Wake Up: **Yes.**
6. Tap on Trusted Devices

Section 2: <u>Trusting (Pairing) the device.</u>

1. Tap on **Add Device**
2. Then it will start a **Bluetooth Discovery** (Searching for Bluetooth devices)
3. Select and Tap on the device and click **OK**
4. It will start the Bluetooth Progress (connecting to the Bluetooth device that you selected)
5. Enter the **Passkey** for the Computer you selected. Default (0000)
6. It will start Verifying the passkey for the computer you selected.
7. On the lower right hand corner of you're monitor on the Task bar on the Bluetooth icon a bubble will appear letting you know that the Palm OS is trying to connect to you're computer.
8. Click on the Bubble or Bluetooth Icon, put in the passkey that was put in on you're Palm OS (0000) click **OK**.
9. If you want to delete a Bluetooth device from the Trusted devices list (Paired Devices) Select the Bluetooth device then Tap on **Details** and Tap **Delete Device** and then **OK**.

Section 3: <u>Creating and Establishing the connection.</u>

1. Tap on **Preferences,** on the upper right side corner tap on the pull down error and select **Connections**.
2. On **Available Connections:** Tap on **Edit**.
3. On Connect to: Select **PC**
4. Via: **Bluetooth**
5. Name: Rename the Connection. Example (Belkin)
6. Device: Tap on to discover the Computer you're going to Hotsync.
7. Select the Computer and Click **OK** and **OK** again.

BELKIN

Section 4: <u>Setting up the Bluetooth Hotsync Operation on the PC.</u>

1. Open you're Bluetooth Neigborhood or Bluetooth Places on you're PC.
2. On the left side click on View my Bluetooth Services or on My Device.
3. Right click on the Serial port and click on Properties.
4. Make sure you have a check mark on Start up Automatically and uncheck Secure connection or Encryption and click on Apply.
5. Get the Serial port number for an Example (Com port 3)

Section 5: <u>Setting up the Com port on the Palm Desktop Software.</u>

1. Right click on the **Palm Icon** on the Lower right corner of the Task Bar.
2. Make sure that **Local Serial** is the only one checked.
3. Click on **Setup**.
4. Click on the **Local** Tab.
5. On the Serial Port select the com port that was on Section 4 on number 5 (Com port 3). The Speed leave as default, then click or Apply.

Section 6: <u>Performing the Hotsync Operation on the Sony Clie</u>

1. Tap the HotSync Icon on the Sony Clie.
2. Tap on the Pull down error and select the connection that you created on like on Section 3 on number 5 (Belkin)
3. Then Tap on the Hotsync Icon and should start performing a Hotsync Operation.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com