




### Compatibility:

- 864TRV Fireplace
- 864ST Fireplace
- 864HO Fireplace

### Installation Details

### Packing List:

- Face
- Face Mounting Brackets (upper and lower sets)
- (2) Face Brackets (w screws)
- (12) 8-32 Nuts
- (2) 10-24 1-1/2" Screws




**NOTE:**

This face has an adjustable bracket that allows for different facing depths to be tucked under the face.

### Special Instructions for 864HO Fireplaces


This face requires the outer grill deflectors to be removed. See the instructions below.





## Installation

- 1 Attach the brackets to the fireplace following the directions below.






## 864TRV Rectangular Face

Black 95800623

Nickel 95800624


- The facing and hearth (if applicable) must be installed prior to attaching the face. See the installation manual for complete details.

Raised  
Fireplaces



Note how the tile is 1"  
(maximum) above the  
base of the fireplace.


Floor-Level  
Fireplaces



Maximum 1" Hearth




3 Install the face following the directions below.



### **Plated Surfaces**

Use denatured alcohol and a soft cloth to clean plated surfaces. Marks left on the surface may damage the face.



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>